

COMPLETE SPRAYER PARTS LIST

ITEM NO.	PART NO.	DESCRIPTION	ITEM NO.	PART NO.	DESCRIPTION
1	301-189	Shield- Front	35	111-037	Screw (8)
2	301-092	Shield- Rear			
3	301-105	Hook			
4	100-360	Screw (2)			
5	100-312	Screw (4)	41	117-052	Screws (3)
6	301-320	Cover	42	101-060	Label High Voltage
7	301-333	Connecting Rod Ass'y (10/11 Series)	43	301-046	Rod End
	301-291	Connecting Rod Ass'y (8 Series)	44	301-237	Pulley, Cog
8	189-048	Retaining Ring (2)	45	301-231	Cog Belt
9	189-046	Coupling Set	46	189-427	Air Wheel (2)
10	301-047	Sleeve Bearing	47	143-029	Set Collar (2)
11	189-047	Coupling Cover	48	167-014	Spacer (2)
12	301-193	Tensioner Ass'y			
13	111-044	Screw (2)	50	113-055	Axle
14	140-029	Washer (2)	51	301-134	Stopper (2)
15	113-023	Washer, (2)	52	301-517-99	Suction Ass'y 16" (5 gal)
16	111-037	Screw (4)	53	301-543-99	Suction Ass'y 36" (55 gal)
17	301-135	Grommet (6)	54	141-010	Inlet Strainer
18	100-332	Retaining Ring	55	301-106A	1 1/4 HPDC Motor (10/11 Series)
19	301-139	Woodruff Key			1 HPDC Motor (8 Series)
			56	301-089	Fan Cover
21	301-048	Spacer - Tube (2)	57	113-022	Nut (4)
22	100-328	Stud (2)	58	113-023	Washer, Lock (4)
23	140-035	Washer, Lock (2)	59	140-029	Washer (4)
24	140-051	Nut (2)	60	100-028	Plug 1/4 NPT
25	301-173	Bracket - Return Tube	61	301-190	Fan
26	136-033A	Screw (3)	62	130-191	Retaining Clip, Fan
27	301-099	Screw (3)	63	301-336	Gearbox 1" (10/11 Series)
28	140-051	Nut (3)	64	301-060A	Gearbox 3/4" (8 Series)
29	301-233	Sheave	65	301-337	Screw (2)
30	115-041	Set Screw (4)	66	301-316	Rubber Edge (1.17")
31	112-029	Key			(makes two)
32	301-321	Cover			
33	301-205	Frame			
34	301-318	Pressure Control Ass'y			

LABEL KITS

<u>PART NO.</u>	<u>UNIT</u>
301-430	AIRLESSCO SL810
301-435	ALLPRO 810E
301-431	AIRLESSCO SL1100
301-436	ALLPRO 1000E

SUPPLEMENTAL 230 VOLT PARTS LIST

MODEL	MOTOR & PART NO.	FUSE & PART NO.	BOARD
8 SERIES	1 HP - P.N. 301-058A	12 AMP P.N. 331-165	P.N. 301-364
10/11 SERIES	1.25 HP - P.N. 301-255A	15 AMP - P.N. 331-256	P.N. 301-364